

Command Source Faceplate Help

Command Source Indicators



Device in Program



Device in Maintenance



Override



Device Out of Service



Device in Operator



Device in External



Hand (Local)



Device not operating under normal command source

Commands



Operator Request. Place the device in Operator Control



Program Request. Place the device in Program Control



Maintenance Release. Release the device control to the next in line source



Operator Lock Request. Lock the device in Operator Control



Maintenance Request. Place the device in Maintenance Control

Totem Pole

The Command Source Totem Pole on the faceplate indicates who is currently controlling the device as well as the sources requesting control of the device. The left most highlighted source has control. Once that source releases control, then the device will be under control of the next highlighted source.

In the example below, the device is “Out of Service” which is the left most highlighted source. Once the device is placed back in service, the device will be in “Maintenance”, control, which is the next highlighted source.

