

High/Low Selector Faceplate Help

Status Indicators



Invalid configuration



Output CV clamped to min/max