









Digital Input Faceplate Help

Status Indicators

	Invalid configuration		Alarm Inhibit (Suppressed or Disabled)
	Data quality bad / failure		Maintenance Bypass active
	Data quality degraded / uncertain		Device in Simulation or Test
	Input matches target		Input does not match target

Alarms






Discrete Input Alarm (Target Disagree)

This alarm triggers when the input Process Variable is not equal to the Target Process Variable and the Gate value is Enabled.



I/O Fault Alarm

The I/O Fault Alarm is triggered when a controller hardware or communication fault is detected.




Alarm Icons

	Urgent		High		Medium
	Low		Out of Alarm Ack Required		

Alarm Commands

	Acknowledge Alarm. This command acknowledges an alarm that has been configured with "Ack Required".
	Acknowledge and Reset all alarms for an object. This acknowledges all active alarms and resets all alarms that have been configured with "Reset Required".

Alarm States

	Alarm Suppressed (disabled by controller)
	Alarm Disabled (by user)
	Alarm Shelved (logged but not annunciated)