

# Enhanced PID Faceplate Help

## Status Indicators



Invalid configuration



Auto Loop mode



Cascade Loop mode



Communication failure



Manual Loop mode

## Threshold Indicators



High-High Threshold exceeded



High Threshold exceeded



Low-Low Threshold exceeded



Low Threshold exceeded

## Deviation Indicators



High Deviation exceeded



High-High Deviation exceeded



Low Deviation exceeded



Low-Low Deviation exceeded

## Command Source Indicators



Device in Program



Override



Device not operating under normal command source



Device in Operator



Hand (Local)

## Commands



Program Control Request



Request Cascade Loop Mode. Available when in Operator Control & Cascade Mode Enabled



Request Manual Loop. Available when in Operator Control



Operator Control Request

Request Auto Loop Mode. Available when in Operator Control