

Alarm Faceplate Help

Alarm Icons



Urgent



High



Medium



Low



Out of Alarm Ack Required

Alarm Commands



Acknowledge Alarm. This command acknowledges an alarm that has been configured with “Ack Required”.



Acknowledge and Reset all alarms for an object. This acknowledges all active alarms and resets all alarms that have been configured with “Reset Required”.

Alarm States



Alarm Suppressed (disabled by controller)



Alarm Disabled (by user)



Alarm Shelved (logged but not annunciated)