Lead / Lag / Standby Faceplate Help

Status Indicators

- Invalid configuration
- Device not ready to operate
- Motor Running
- Motor Idle
- Alarm Inhibit (Suppressed or Disabled)
- Maintenance Bypass active
- Motor Not Controllable

Command Source Indicators

- Device in Program
- Device in Maintenance
- Override
- Device not operating under normal command source
- Device in Operator
- Out of Service
- Hand (Local)
- External

Interlocks and Permissives



- One or more conditions not OK
- Non-Bypassed conditions OK
- All conditions OK, Bypass Active
- All conditions OK

Commands

- Start Motor Group. Available in Operator or Maintenance Command Source
- Rotate Motor Assignments (demote lead to end of list). Available in Operator or Maintenance Command Source.
- Stop Motor Group. Available in Operator or Maintenance Command Source

Alarms

Interlock Trip Alarm

The Interlock Trip Alarm is triggered when an interlock condition causes the motor group to stop.

No Motors to Start and No Motors to Stop Alarms

These alarms trigger when there are no motors that can be started or stopped to meet the current demand.

Alarm Icons

 Urgent

 High

 Medium

 Low

 Out of Alarm Ack Required

Alarm Commands

Acknowledge Alarm. This command acknowledges an alarm that has been configured with “Ack Required”.

Acknowledge and Reset all alarms for an object. This acknowledges all active alarms and resets all alarms that have been configured with “Reset Required”.

Alarm States

 Alarm Suppressed (disabled by controller)

 Alarm Disabled (by user)

 Alarm Shelved (logged but not annunciated)